

BABY CRY SIGNALER

SONIC SITTER

BC 400 Installation

- 1. Plug BC400 into wall outlet.
- 2. Adjust sensitivity.



BC400



The Sonic Sitter, is a small, attractive unit that "immediately alerts you" when your baby starts crying.

The BC 400 has an adjustable sensitivity control & can be set to "<u>alert you to sounds as soft as a baby's whisper</u>".

The BC 400 simply plugs into any outlet in the baby's room.

Your baby is not disturbed, no lamp flashes in the baby's room.

When your baby cries, the BC 400 sends a signal over your home's electrical system to remote receivers, so it is *completely wireless* !!!

The Sonic Sitter also has a built-in indicator light to show you it's working.

You can REST ASSURED that you will always know when your baby is crying & needs you.