

# CentralAlert<sup>™</sup> REAL-TIME BABY CRY SENSOR CA-BX FAQ



# FAQ (FREQENTLY ASKED QUESTIONS)

#### Q: What is the range of the CA-BX?

A: It can work up to 200ft away from the CA360

#### Q: Where should I place the CA-BX ?

A: For optimal results, place it about 2-5 feet away from your baby but keep it out of reach.

#### Q: Can I set the CA-BX such that I will only be alerted when my baby cries louder than usual?

A: Yes, There is a visual loudness indicator to guide you for proper sensitivity setting. See your user manual for more details.

#### Q: How many CA-BX can I have with my CA-360?

A: You can have up to three CA-BX.

## Q: If I have more than one CB-BX, how do I know which one is activated?

A: There is an easy way to assign a number to each of your CA-BX; the activated CA-BX number will be displayed on the CA-360. Please see your manual for more details.

#### Q: Can you elaborate more on Real-Time monitoring and its benefit?

A: The CA-BX Real-Time Features Means the CA-BX will alert you when the baby cries and stops alerting you when the baby stops crying.

## Q: How long will the batteries last and how do I know it is time to replace them?

A: Batteries should last up to 10 months under normal circumstances. You can use the Test button to check your battery power. Please see the user manual for more details.